

Original Operating Instructions V-VTN

V-VTN 16 | 26 | 41



**V-Serie
V-Series**
Drehschieber
Rotary Vane



Table of contents

1	Foreword	4
1.1	Principles	4
1.2	Target group	4
1.3	Supplier documentation and accompanying documents	4
1.4	Abbreviations	4
1.5	Directives, standards, laws	4
1.6	Symbols and meaning	5
1.7	Technical terms and meaning	5
1.8	Copyright	5
2	Safety	6
2.1	Warning instruction markings	6
2.2	General	6
2.3	Designated use	7
2.4	Unacceptable operating modes	7
2.5	Personal qualifications and training	8
2.6	Safety-conscious work	8
2.7	Safety notes for the operator	8
2.8	Safety instructions for installing, commissioning and maintenance	9
2.9	Guarantee conditions	9
3	Transport, storage and disposal	10
3.1	Transportation	10
3.1.1	Unpack and check the delivery condition	10
3.1.2	Lifting and transporting	10
3.2	Storage	11
3.2.1	Ambient conditions for storage	11
3.3	Disposal	11
4	Set up and operation	12
4.1	Setup	12
4.1.1	Datenschild	14
4.2	Description	14
4.3	Areas of application	14
5	Installation	15
5.1	Preparing for installation	15
5.2	Installation	15
5.3	Connecting pipes	16
5.4	Control and relief valve	16
5.5	Connecting the motor	17
6	Commissioning and decommissioning	18
6.1	Commissioning	18
6.1.1	Checking the rotation direction	19
6.2	Decommissioning/ storing	19
6.3	Re-commissioning	19

7	Maintenance and repair	20
7.1	Ensuring operational safety	20
7.2	Maintenance work	20
7.2.1	Air filtering	21
7.2.2	Replacing blades	22
7.3	Reparatur/ Service	23
7.4	Spare parts	24
8	Malfunctions: Causes and elimination	25
9	Technical Data	27

1 Foreword

1.1 Principles

These operating instructions:

- are a part of the following oil-flooded rotary vane vacuum pumps V-VTN 16, V-VTN 26 and V-VTN 41.
- describe how to use them safely and properly in all life phases.
- must be available where the equipment is used.

1.2 Target group

The target group for these instructions is technically trained specialists.

1.3 Supplier documentation and accompanying documents

Document	Contents	No.
Supplier documentation	Operating Instructions	BA 281-EN
	Declaration of Conformit	C 0083-EN
	Declaration of harmlessness	7.7025.003.17
Spare parts' list	Spare parts' document	E 281
Data sheet	Technical data and graphs	D 281
Info sheet	Storage guidelines for machines	I 150
Manufacturer's declaration	EU Directive 2002/95/EG (RoHS)	—

1.4 Abbreviations

Fig.	Figure
V-VTN	Vacuum pump/
m ³ /h	Pumping capacity
mbar (abs.)	Final vacuum, operating vacuum

1.5 Directives, standards, laws

See Conformity Declaration

1.6 Symbols and meaning

Symbol	Explanation
▷	Condition, pre-requisite
####	Instructions, action
a), b),...	Instructions in several steps
⇒	Results
 [-> 14]	Cross reference with page number
	Information, note
	Safety symbol Warns of potential risk of injury Obey all the safety instructions with this symbol in order to avoid injury and death.

1.7 Technical terms and meaning

Term	Explanation
Machine	Pump and motor combination ready to be connected
Motor	Pump drive motor
Vacuum pump	Machine to create a vacuum
Rotary vane	Machine's design or active principle
Pumping capacity	Vacuum pump volume flow related to the condition in the suction connection
Final pressure (abs.)	The maximum vacuum that a pump reaches when the suction opening is closed. Given as absolute pressure.
Permanent vacuum	The vacuum or the suction range at which the pump operates permanently. The permanent vacuum or intake pressure is $\geq$ than the final vacuum and $<$ than the atmospheric pressure..
Noise emission	The noise emitted at a specific loading given as a figure, sound pressure level dB(A) as per EN ISO 3744.

1.8 Copyright

Passing on or copying this document, using and providing information on its contents are prohibited unless expressly permitted.

2 Safety

The manufacturer is not responsible for damage if you do not follow all of this documentation.

2.1 Warning instruction markings

Warning	Danger level	Consequences if not obeyed
 DANGER	immediately imminent danger	Death, severe bodily injury
 WARNING	possible imminent danger	Death, severe bodily injury
 CAUTION	possible hazardous situation	Slight bodily injury
 NOTICE	possible hazardous situation	Material damage

2.2 General

These operating instructions contain basic instructions for installation, commissioning, maintenance and inspection work which must be obeyed to ensure the safe operation of the machine and prevent physical and material damage.

The safety instructions in all sections must be taken into consideration.

The operating instructions must be read by the responsible technical personnel/ operator before installing and commissioning and must be fully understood. The contents of the operating instructions must always be available on site for the technical personnel/ operator. Instructions fixed directly onto the machine must be obeyed and must always remain legible. This applies for example to:

- Symbols for connections
- Data and motor data plate
- Instruction and warning plates

The operator is responsible for observing local regulations.

2.3 Designated use

The machine must only be operated in such areas as are described in the operating instructions:

- only operate the machine in a technically perfect condition
- do not operate the machine when it is only partially assembled
- the machine must only be operated at an ambient temperature and suction temperature of between 5 and 40°C. Please contact us for temperatures outside this range.
- the machine may convey, compress or extract the following media:
 - convey air with a relative humidity of 30 - 90%
 - all non-explosive, non-inflammable, non-aggressive and non-poisonous dry gases and gas air mixtures

2.4 Unacceptable operating modes

- extracting, conveying and compressing explosive, inflammable, aggressive or poisonous media, e.g. dust as per ATEX zone 20-22, solvents as well as gaseous oxygen and other oxidants, extremely damp air, water vapour, traces of oil, oil vapour and grease
- using the machine in non-commercial plants if the necessary precautions and protective measures have not been taken in the plant
- installing in environments that are at risk of explosions
- using the machine in areas with ionising radiation
- back pressures on the outlet side of more than +0,1bars
- modifications to the machine and accessories

2.5 Personal qualifications and training

- Ensure that people entrusted with working on the machine have read and understood these operating instructions before starting work, particularly the safety instructions for installation, commissioning, maintenance and inspection work.
- Manage the responsibilities, competence and monitoring of staff
- all work must only be carried out by technical specialists:
 - Installation, commissioning, maintenance and inspection work
 - Working with electricity
- personnel being trained to work on the machine must be supervised by technical specialists only

2.6 Safety-conscious work

The following safety regulations apply in addition to the safety instructions and intended use listed in these instructions:

- Accident prevention regulations, safety and operating regulations
- the standards and laws in force

2.7 Safety notes for the operator

- hot parts of the machine must not be accessible during operation or must be fitted with a guard
- People must not be endangered by the free extraction or discharge of pumped media
- Risks arising from electrical energy must be eliminated.

2.8 Safety instructions for installing, commissioning and maintenance

- The operator will ensure that any installation, commissioning and maintenance work is carried out by authorised, qualified specialists who have gained sufficient information by an in-depth study of the operating instructions.
- Only work on the machine when it is idle and cannot be switched on again
- Ensure that you follow the procedure for decommissioning the machine described in the operating instructions.
- Fit or start up safety and protective devices again immediately after finishing work.
- Conversion work or modifications to the machine are only permissible with the manufacturer's consent.
- Only use original parts or parts approved by the manufacturer. The use of other parts may invalidate liability for any consequences arising.
- Keep unauthorised people away from the machine

2.9 Guarantee conditions

The manufacturer's guarantee or warranty will no longer apply in the following cases:

- Improper use
- Not complying with these instructions
- Operation by insufficiently qualified staff
- Using spare parts that have not been approved by **Gardner Denver Schopfheim GmbH**
- Unauthorised modifications to the machine or the accessories supplied by **Gardner Denver Schopfheim GmbH**

3 Transport, storage and disposal

3.1 Transportation

3.1.1 Unpack and check the delivery condition

- a) Unpack the machine on receipt and check for transport damage.
- b) Notify the manufacturer of transport damage immediately
- c) Dispose of the packaging in accordance with the local regulations in force.

3.1.2 Lifting and transporting



WARNING

Death or limbs crushed as a result of the items being transported falling or tipping over.

- ▷ When transporting with the lifting device remember:
 - a) Select the lifting device suitable for the total weight to be transported.
 - b) Ensure that the machine cannot tip and fall.
 - c) Do not stop under a suspended load.
 - d) Put the goods to be conveyed on a horizontal base.

Lifting device/ Transporting with a crane



WARNING

Bodily injury resulting from improper operation

- a) Loads crosswise to the ring level are not permitted.
 - b) Avoid impact stress.
-
- a) Tighten the eyebolts (Fig. 1/1) firmly.
 - b) The machine must be suspended on the eyebolt using the lifting device for lifting and transporting.




Fig. 1 Lifting and transporting

1 Eyebolt

3.2 Storage

NOTICE

Material damage caused by improper storage.

- ▷ Ensure that the storage area meets the following conditions:
 - a) dust free
 - b) vibration free

3.2.1 Ambient conditions for storage

Ambient conditions	Value
Relative humidity	0 % to 80 %
Lagertemperatur	-10°C to +60°C



The machine must be stored in a dry environment with normal air humidity. It should not be stored for more than 6 months.

📄 see Info “Machine storage guidelines”, Page 4

3.3 Disposal



WARNING

Danger from inflammable, corrosive or poisonous substances.

Machines that come into contact with hazardous substances must be decontaminated before disposal.

- ▷ When disposing ensure the following:
 - a) Collect oils and grease separately and dispose of in accordance with the local regulations in force.
 - b) Do not mix solvents, limescale removers and paint residues
 - c) Remove components and dispose of them in accordance with the local regulations in force.
 - d) Dispose of the machine in accordance with the national and local regulations in force.
 - e) Parts subject to wear and tear (marked as such in the spare parts list) are special waste and must be disposed of in accordance with the national and local waste laws.

4 Set up and operation

4.1 Setup




Fig. 2 Vacuum pump V-VTN (01) / V-VTN (02)

- | | | | |
|----------------------|-------------------------|----------|--------------------|
| A | Vacuum connection | E | Cooling air inlet |
| B | Exhaust air outlet | F | Cooling air outlet |
| C | Vacuum regulating valve | N | Data plate |
| C₁ | Vacuum safety valve | | |




Fig. 3 Vacuum pump V-VTN

- | | | | |
|----------------------|----------------------------|----------|--------------------------|
| G | Outlet grid | N | Data plate |
| G₁ | Inlet grating | O | Rotation direction plate |
| J | Plug connection (optional) | | |

Set up and operation

4.1.1 Datenschild




Fig. 4 Data plate (example)

4.2 Description

The V-VTN model range has a connecting thread on the suction side and an exhaust silencer on the pressure side. The aspirated air is cleaned by an inbuilt fine micro filter.

The motor and the pump have a common shaft.

The vacuum pumps V-VTN are located in a plastic sound cover. Inside the sound cover is also a fan that provides cooling.

The V-VTN (02) has a vacuum regulating valve fitted as standard (Fig. 2/C) that enables the vacuum to be set to the required values which have an upper limit.

4.3 Areas of application

These dry running rotary vane vacuum pumps V-VTN 16 bis V-VTN 41 are suitable for evacuating closed systems and for a permanent vacuum in the intake pressure range 150 - 1000 mbars (abs.).

The pumping capacity with unrestricted suction is 15, 25 and 40 m³/h at 50 Hz. Data sheet D 281 shows the dependency of the pumping capacity on the intake pressure

These dry running machines are suitable for conveying air with a relative humidity of 30 - 90 %.



If the unit is switched on more frequently (at regular intervals of about 10 times an hour) or at higher ambient temperatures and intake temperatures, the excess temperature limit of the motor winding and the bearings may be exceeded.

Please contact the manufacturer should the unit be used under such conditions.



If it is installed in the open air the unit must be protected from environmental influences, (e.g. by a protective roof).

5 Installation

5.1 Preparing for installation

Check the following points:

- Machine freely accessible from all sides
- Do not close ventilation grids and holes
- Sufficient room for installing and removing pipes and for maintenance work, particularly for installing and dismantling the machine
- No external vibration effect
- Do not suck any hot exhaust air from other machines into the cooling system.



To remove the outlet grid (Fig. 3/G) and the inlet grating (Fig. 3/G₁) at least 30 cm of space must be available for maintenance work. You must also ensure that the cooling air inlets (Fig. 2/E) and cooling air outlets (Fig. 2/F) must be at least 10 cm away from the nearest wall (outgoing cooling air must not be sucked in again).

5.2 Installation

NOTICE

The machine may only be operated when it is set up horizontally.

Material damage resulting from the machine tipping over and falling.

When installed at more than 1000 m above sea level a reduction in power is noticeable. In this case we would ask you to contact us.

Ensure that the foundation complies with the following conditions:

- Level and straight
- The bearing surface must be able to bear the weight of the machine



It must be possible to install the machine on a firm foundation without anchoring. When installing on a substructure we recommend fixing with flexible buffers.

5.3 Connecting pipes

- a) Vacuum connection at (Fig. 2/A).

NOTICE

Material damage resulting from the forces and torques of the pipes on the unit being too high.
screw pipes in by hand.

The pumping capacity of the vacuum pump is reduced if the suction pipe is too narrow and/or too long.

- b) Check to ensure the suction pipe is connected correctly.

NOTICE

Length of the connection pipes

With connection pipes that have the same pipe cross section as the machine connection and are more than 3m long, a non-return valve especially for the purpose must be installed in order to avoid reverse operation when the machine has stopped.

5.4 Control and relief valve

The vacuum can be set by turning the control knob (Fig. 2/C) as shown on the symbol fitted to the button.

NOTICE

Do not operate without the standard control and relief valve.

If the permissible vacuum is exceeded (see data plate) the machine may be damaged.

5.5 Connecting the motor



DANGER

Danger of death if the electrical installation has not been done professionally.

The electrical installation must only be done by a qualified electrician observing EN 60204. The operating company has to provide the main switch.

- a) The electrical motor data can be found on the data plate (Fig. 2/N) or the motor data plate. The motors comply with DIN EN 60034 and are in protection class IP 55 and insulation class F. The appropriate connection diagram is located in the motor's terminal box (not for the plug connection version). The motor data must be compared with the data of the existing mains network (current type, voltage, network frequency, permitted current value).
- b) Connect the motor via the plug connection (Fig. 3/J) or a motor protection switch (for safety reasons a motor protection switch is required and cable fitting must be provided to provide strain relief for the connection cable). We recommend using motor protection switches with delayed switch off, depending on possible excess current. Temporary excess current may occur when the machine is started cold.

NOTICE

Power supply

The conditions at the installation location must match the information on the motor data plate. Without derating the following is permissible:

- $\pm 5\%$ voltage deviation
- $\pm 2\%$ Frequency deviation

6 Commissioning and decommissioning

6.1 Commissioning



WARNING

Improper use

May lead to severe or fatal injuries. Therefore be sure to obey the safety instructions.



CAUTION

Noise emission

The highest noise pressure levels measured as per EN ISO 3744 are given in Section 9. When spending a long time in the vicinity of the running machine use ear protectors to avoid permanent damage to your hearing.

NOTICE

Wait until the machine stops

The machine must only be switched on again after it stops.

6.1.1 Checking the rotation direction

- ▷ The drive shaft direction of rotation is shown by the rotation direction arrow (Fig. 2/O).
- a) Start the motor briefly (max. two seconds) to check the direction of rotation. When looking at the motor fan, it must rotate clockwise.



The suction pipe must not be connected when starting up like this.

NOTICE

Incorrect direction of rotation

Running the machine in reverse for a long time may cause damage to the blades which may lead to the blades breaking. Use a phase sequence indicator to check the direction of rotation (**anti-clockwise rotating field**).

6.2 Decommissioning/ storing

Stop the machine

- a) Switch the machine off.
- b) If available close the cut off device in the suction and pressure pipe.
- c) Disconnect the machine from the electricity source.
- d) Depressurise the machine: Open the pipes slowly. ⇨ The pressure reduces slowly.
- e) Remove the pipes and hoses.
- f) Seal the connections for suction and discharge nozzles with adhesive foil.

📄 see also Section 3.2.1, Page 11

6.3 Re-commissioning

- a) Check the condition of the machine (cleanliness, cabling etc.).
- 📄 For installation see Section 5 Page 15
- 📄 For commissioning see Section 6.1 Page 18

7 Maintenance and repair



DANGER

Danger of death from touching live parts.

Before maintenance work disconnect the machine by pressing the main switch or unplugging it and ensure that it cannot be turned on again.



WARNING

Hot surfaces and equipment

During maintenance work there is the danger of getting burnt on hot components and by the machine lubricating oil.

Wait for the machine to cool down.

7.1 Ensuring operational safety

Regular maintenance work must be carried out in order to ensure operational safety.

Maintenance intervals also depend on the operational demands on the machine.

With any work observe the safety instructions described in Section 2.8 “Safety notes for installation, commissioning and maintenance”.

The whole unit should always be kept in a clean condition.

7.2 Maintenance work

Interval	Maintenance to be carried out	Section
monthly	Check the pipes and screws for leaks and to ensure they are seated properly and if necessary seal again or tighten up.	—
monthly	Check the terminal box and cable inlet holes for leaks and if necessary re-seal.	—
monthly	Clean the regulating valve and ventilation slots on the machine and the motor cooling ribs. If there is a great deal of dust in the spaces on the cooling ribs clean them.	—
—	The machine's bearings are permanently lubricated and do not require re-lubricating.	—
monthly / every 6 months	Clean or replace filter cartridges	7.2.1
V-VTN 16: 7,000 h / 1,000 h V-VTN 26: 5,000 h / 1,000 h V-VTN 41: 3,000 h / 1,000 h	Check blades ⇔ Replace blades	7.2.2

7.2.1 Air filtering




Fig. 5 Air filtering

- G** Outlet grid
- b** Housing lid
- e** Filterpatrone
- m** Knurled knob
- s** Screw cap

NOTICE

Insufficient maintenance on the air filter

The power of the machine lessens and damage may occur to the machine.

Die Filterpatrone (Fig. 5/e) für Saugluft ist monatlich oder je nach Verunreinigung öfters durch Ausblasen von innen nach außen zu reinigen. In spite of cleaning the filter its separation efficiency will continue to deteriorate. Therefore the filters should be replaced every six months.

Changing filters:

Unscrew the outlet grid (5/G).

Undo the screw cap (Fig. 5/s) and the knurled knob (Fig. 5/m). Remove and clean or replace filter cartridges (Fig. 5/e). Reassemble in reverse order.




Fig. 6 Filterpatrone ausblasen

- 1** Filterpatrone
- 2** Druckluft



WARNING

Danger of injury when dealing with compressed air.

When blowing through with compressed air, solid particles may be carried along or powder dust swirling around may cause injury to the eyes. Therefore, when cleaning with compressed air always wear goggles and a dust mask.

7.2.2 Replacing blades




Fig. 7 Changing blades

- O₁** Direction of rotation
- X** Minimum height
- Y** Slanting side of the blade
- Z** Drilled holes in the housing
- b** Housing lid
- d** Blade

Checking blades:

V-VTN 16 / 26 have 6 carbon blades and V-VTN 41 has 7 carbon blades that wear out gradually during operation.

V-VTN 16: First check after 7,000 operating hours, then every 1,000 operating hours.

V-VTN 26: First check after 5,000 operating hours, then every 1,000 operating hours.

V-VTN 41: First check after 3,000 operating hours, then every 1,000 operating hours.

Unscrew the outlet grid (Fig. 5/G). Unscrew the housing cover (Fig. 7/b) from the housing. Remove the blades (Fig. 7/d) to be checked. All blades must have a minimum height (Fig. 7/X):

Type _____ X (minimum height)

V-VTN 16, 26 24 mm

V-VTN 41 35 mm



The blades must only be changed as a set.

Changing blades: If you detect during the blade check that the minimum height has been reached or it has fallen below the minimum height, the blade set must be changed. Blow out the housing and the rotor slot. Insert the blades into the rotor slot. When doing this you must ensure that the blades with the sloping side (Fig. 7/Y) point outwards and the direction of rotation of these sloping sides (Fig. 7/O₁) matches that of the drilled holes for the housing (Fig. 7/Z). Screw on the housing lid (Fig. 7/b) and outlet grid (Fig. 6/G). Before starting up check that the blades run freely by moving the fan round, for it unscrew the inlet grating (Fig. 2/G₁).

7.3 Reparatur/ Service

- a) For on site repair work the motor must be disconnected from the mains by a qualified electrician so that it cannot be started up again accidentally. For repairs use the manufacturer, its branch offices or authorised dealers. Please contact the manufacturer for the address of the service centre responsible for you (see Manufacturer's address).

NOTICE

For each machine that is sent to an Elmo Riet-schle Service centre for inspection, maintenance or repair, a fully completed, signed declaration of harmlessness must be enclosed.

The declaration of harmlessness is part of the supplier's documentation.

- b) After a repair or re-commissioning, the actions listed under „Installation“ and „Commissioning“ must be carried out as for initial commissioning.

Gardner Denver		Formular Unbedenklichkeitsklärung für Vakuumpumpen und Komponenten		7.7025.003.17 GDS Seite 1 von 1
Gardner Denver Schopfheim GmbH Bürgermeister-Str. 70/51 Schopfheim Telefon: +49(0)7823952-0 Fax: +49(0)7823952-300				
Die Reparatur ändert die Wartung von Vakuumpumpen und Komponenten wird nur durchgeführt, wenn eine bereits und vollständig ausgefüllte Erklärung vorliegt. Ist das nicht der Fall, kann nicht mit dem Reparaturarbeiten begonnen werden und Verspätungen sind die Folge. Diese Erklärung darf nur vom autorisierten Fachpersonal ausgefüllt und unterschrieben werden.				
1. Art der Vakuumpumpe / Komponente		2. Grund für die Einweisung		
Typische Bezeichnung: Maschinen-Nr.: Auftrags-Nr.: Lieferdatum:				
3. Zustand der Vakuumpumpe / Komponente		4. Einmalbedingte Kontamination der Vakuumpumpen / Komponenten		
Wurde diese benutzt? JA ☐ NEIN ☐		Welches Schmiermittel wurde verwendet?		
Wurde die Pumpenkomponente ersetzt?		Trostsch JA ☐ NEIN ☐		
(Immerstoffwechsel) JA ☐ NEIN ☐		Messungspunkt? JA ☐ NEIN ☐		
Ist die Pumpenkomponente gereinigt, dekontaminiert, (je und hatte zuvor frei von gasdichtungsbedingten Schadstoffen)? JA ☐		Fremdstoff? JA ☐ NEIN ☐		
Reinigungsart:		Reinigungsart? JA ☐ NEIN ☐		
Reinigungsmethode:				
*) Mitunter, jedoch oder reduzierte kontaminierte Vakuumpumpen / Komponenten werden nur bei Nachweis einer verschleißfreien Reinigung entlassen.				
Art der Substanz oder sonstiger, gefährlicher Reaktionsprodukte, mit denen die Vakuumpumpen / Komponenten in Kontakt kamen				
Handelsname, Produktname	Chemische Bezeichnung	Gefahren	Maßnahmen bei Freisetzen	Erste Hilfe bei Unfällen
1.				
2.				
3.				
Persönliche Schutzmaßnahmen:				
Gefährliche Zerstückungsprodukte bei technischer Belastung JA ☐ NEIN ☐				
Wischer:				
*) Rückverpflichtung Erklärung				
Wir versichern, dass die Angaben in dieser Erklärung wahrheitsgemäß und vollständig sind, und ich als Unterzeichner in dem Maße, wie ich bekannt ist, die Angaben bestätigen. Wir verpflichten uns, den Auftraggeber von durch unvollständige oder unrichtige Angaben entstehenden Schadensersatzansprüchen Dritter freizustellen. Uns ist bekannt, dass wir unabhängig von dieser Erklärung gegenüber Dritten - sowie insbesondere die mit der Handhabung des Produkts verbundenen Mitarbeiter des Auftraggebers - geschuldet haben.				
Firma: _____ P.L.C. OR _____				
Telefon: _____ Telefax: _____				
Name des Druck- _____ Postfach: _____				
Datum: _____ Firmenstempel: _____				
Rechtsverbindliche Unterschrift: _____				
TÜS-Gar / max 7.7025.003.17/16 (Einschleifende Seite 10) (Einschleifende Seite 10) (Einschleifende Seite 10)				

Fig. 8 Clearance certificate 7.7025.003.17

7.4 Spare parts




Fig. 9 Spare parts list (example)

Order spare parts in accordance with the:

- **Spare parts list:**
E 281 → V-VTN 16 - V-VTN 41
 - Download the PDF file:
<http://www.gd-elmorietschle.com>
 - Downloads
 - Product Documents
 - V-Series → Spare Parts
 - Parts subject to wear and gaskets are indicated separately on the list.
- **Web site:**
<http://www.service-er.de>
 - Select the type, size and design.

NOTICE

Only use original spare parts or parts approved by the manufacturer. The use of other parts may lead to malfunctions and invalidate liability or the guarantee for any consequences arising.



Fig. 10 Web site
<http://www.service-er.de>

8 Malfunctions: Causes and elimination

Fault	Cause	Troubleshooting	Important
Machine is switched off by the motor protection switch	Mains voltage/ Frequency does not correspond with the motor data	Check by qualified electrician	Section 5.5
	Connection to motor terminal board is not correct		
	Motor protection switch is not set correctly		
	Motor protection switch is triggered too quickly	Use a motor protection switch with an overload-dependent delayed switch off that takes into consideration the short term excess current at start up (version with short circuit and overload trigger as per VDE 0660 Part 2 or IEC 947-4)	
	The regulating valve is dirty so that the permissible vacuum value is exceeded.	Clean or replace the regulating valve	Section 7.2 Section 7.4
Pumping capacity is insufficient	The intake filter is dirty	Clean or replace the intake filter	Section 7.2.1 Section 7.4
	The suction pipe is too long or too narrow	Check the hose or the pipe	Section 5.3
	Machine or system leaking	Check the pipework and screw connections for leaks and to ensure that they are firmly seated.	Section 7.2
	Blades are damaged	Replace blades	Section 7.2.2 Section 7.4

Malfunctions: Causes and elimination

Fault	Cause	Troubleshooting	Important
Final pressure (max. vacuum) is not reached	Machine or system leaking	Check the pipework and screw connections for leaks and to ensure that they are firmly seated.	Section 7.2
	Blades are worn or damaged	Replace blades	Section 7.2.2 Section 7.4
Machine gets too hot	Ambient or intake temperature is too high	Ensure it is being used properly	Section 2.3
	Cooling air supply is obstructed	Check environmental conditions	Section 5.1
		Clean ventilation slots	Section 7.2
	The regulating valve is dirty so that the permissible vacuum value is exceeded.	Clean or replace the regulating valve	Section 7.2 Section 7.4
The machine makes an abnormal noise	The compressor housing is worn (chatter marks)	Repair by manufacturer or authorised workshop	Elmo Rietschle Service
	The regulating valve is vibrating	Replace the valve	Section 7.4
	Blades are damaged	Replace blades	Section 7.2.2 Section 7.4
Please contact Elmo Rietschle Service for other malfunctions or those that cannot be eliminated.			

9 Technical Data

V-VTN		16	26	41
Sound pressure level (max.) EN ISO 3744	50 Hz		71	
Tolerance ± 3 dB(A)	60 Hz		74	
Weight (max.)	3 ~		30.5	
	1 ~		31.7	
Length	mm		489	
Width	mm		245	
Height	mm		283	
Vacuum connection		G 1/2	G 1/2	G 3/4




Fig. 11 Data sheet (example)

You will find more technical data on the data sheet **D 281**

- Download the PDF file
D 281 → V-VTN 16 - V-VTN 41
- Download the PDF:
<http://www.gd-elmorietschle.com>
→ Downloads
→ Product Documents
→ V-Series → Data Sheets

NOTICE

Subject to technical changes.



www.gd-elmorietschle.com
er.de@gardnerdenver.com

**Gardner Denver
Schopfheim GmbH**
Roggenbachstraße 58
79650 Schopfheim · Deutschland
Tel. +49 7622 392-0
Fax +49 7622 392-300

**Gardner
Denver**

Elmo Rietschle is a brand of
Gardner Denver's Industrial Products
Division and part of Blower Operations.

EC - declaration of conformity 2006/42/EC

Hereby the manufacturer confirms: Gardner Denver Schopfheim GmbH
Postfach 1260
D-79642 Schopfheim

that the machine: Vacuum pump

of the: Series: V-VTN
Type: V-VTN 6, V-VTN 10, V-VTN 15,
V-VTN 25, V-VTN 40, V-VTN 60
V-VTN 16, V-VTN 26, V-VTN 41

Is conform to the regulations of the guideline indicated above.

The following harmonized and national standards and specifications are applied:

EN 1012-1:1996 Compressors and vacuum pumps — Safety requirements — Part 1: Compressors

EN 1012-2:1996 Compressors and vacuum pumps — Safety requirements — Part 2: Vacuum pumps

These declarations of conformity are invalid when the machine has been modified without prior approval by us and the approval has been documented in writing.

Name and address of the EC person in charge for documentation Wolfgang Darsch
Postfach 1260
D-79642 Schopfheim

Gardner Denver Schopfheim GmbH
Schopfheim, 01.12.2009



Dr. Friedrich Justen, Director Engineering

Fax: +49/(0)7622/392-300

This declaration must only be filled in and signed by authorised qualified staff.