

 BEACONMEDÆS™	Instructions for Loading HMI Program from CF card to HMI
Document No. QAP-CLT-WI-010ao	Issue Date: 11/13/06
Revision No. A	Revision Date: Initial Release

1.0 Purpose

To provide instruction for loading HMI program from CF card to HMI.

2.0 Scope

This instruction pertains to any control panel with an HMI.

3.0 Responsibilities

Assembly employees load the HMI program according to the following instructions.

4.0 Definitions

HMI – human machine interface

CF card – compact flash card

5.0 Instructions

1. Turn power off to HMI using DS-7.
2. Insert CF card in Slot (upper right on back of HMI)
3. Turn CF switch on back of HMI to on.
4. Turn power on to HMI using DS-7.
5. Within 1 second press and hold upper left and lower left corners of HMI screen.
6. After approx. 3 seconds screen will display “CF card check in progress”.
7. After approx 15 seconds “Installing” will display on screen
8. After approx 20 seconds “Install is completed. Restart now.” Will display on screen.
9. After approx 20 seconds correct HMI screen will display.
10. Turn CF switch on back of HMI to off.
11. Remove card by pushing button just above CF card slot.
12. HMI program is now loaded.

Revision History

Rev.	Date	Description of Change	Approver
A	11-13-06	Initial Release	Tim Hornbuckle

Controlled Work Instruction – Do Not Copy